

Daytime Telephone Use with After-Hours Polling

If you routinely poll data from POS servers, time clocks, laboratory instruments, energy management, or other systems, the Teltone Line Sharing Switch and Polling Controller let you connect these devices to the telephone line and do the polling at night. This configuration, illustrated in Figure 1, requires only one line for up to four devices and insures daytime availability of the telephone line.

To utilize this configuration, connect the daytime telephone to Port 1 of the Line Sharing Switch and connect the devices requiring after-hours polling to Ports 2-4.

The Line Sharing Switch and Polling Controller Reference Manuals are available for download at www.teltone.com.




Figure 1